

Experiment Six
Fundamentals of Electromagnetics Lab
EECE2530/1

Michael BRODSKIY
Brodskiy.M@Northeastern.edu

November 15, 2023

Date Performed:	November 8, 2023
Partners:	Manas MAHAJAN & Priyam MODI
Instructor:	Professor MARENGO-FUENTES
TAs:	Nicolas CASILLI & Farah BEN AYED

Abstract

The goal of this laboratory experiment is to determine certain quantities, such as the “dog-leg path differential” and refraction index of the plexi-glass from measurements taken. A laser is pointed at the plexi-glass shape and quantities are measured in certain angles to determine these.

KEYWORDS: dog-leg, refraction index, plexi-glass, laser

1 Equipment

Available equipment included:

- Class II Lasers with AC Power Adapter Switch
- Ruler
- Rotating Base with Tick Marks
- Samples to Measure Optical Properties:
 - Transparent Acrylic Half-Disk
 - Transparent Acrylic Plate

2 Introduction & Objectives

This experiment contains two parts: one in which the refraction index of the material is determined, and one in which the height difference of the dog-leg path is estimated.

For the refraction index measurement, we began by placing the plexi-glass shape into a slot on a rotating base. This rotating base had designated tick marks indicating various angles. A total of 17 measurements were taken, beginning from -80° , and stepping in 10° increments up to 80° .

For the height differential, four measurements were taken, beginning from 0° , and increasing in 20° increments up to 60° . A derivation for a formula to determine the differential is then performed and used to find the value of the difference.

3 Results & Analysis

3.1 Part I

The table below shows our gathered data for the first part of the experiment:

$\theta_i [^\circ]$	$\theta_t [^\circ]$
-80	42
-70	39
-60	36
-50	32
-40	25
-30	20
-20	14
-10	9
0	2
10	4
20	11
30	17
40	22
50	27
60	32
70	37
80	41

We can use the values in the table to estimate the index of refraction. It should be approximately the same for each incident angle. The process to find the index of refraction is applied in the example below to 80° :

$$n_1 \sin(\theta_i) = n_2 \sin(\theta_t)$$

$$n_1 = 1, \quad \theta_i = 80, \quad \theta_t = 41$$

$$n_2 = \frac{\sin(80)}{\sin(41)}$$

$$n_2 \approx 1.472$$

This process was repeated for all values to get:

$\theta_i [^\circ]$	n_2
-80	1.472
-70	1.493
-60	1.473
-50	1.446
-40	1.521
-30	1.462
-20	1.414
-10	1.11
0	0
10	2.489
20	1.792
30	1.71
40	1.716
50	1.687
60	1.634
70	1.561
80	1.501

We should get an approximate estimate for the refraction index by taking the average of all the numbers from the table above. In doing so, we find that $n_{avg} \approx 1.49\bar{8}$. Looking up the value, the expected index of refraction should be 1.4899. Thus, our percent error is:

$$\frac{|1.49\bar{8} - 1.4899|}{1.4899} \cdot 100 = .6029\%$$

Thus, we can see that our measurements were fairly accurate.

3.2 Part II

For Part II, our data was as follows:

$$t = 35[\text{mm}]$$

$$0[^\circ] \rightarrow 20[^\circ] = 8[\text{mm}]$$

$$0[^\circ] \rightarrow 40[^\circ] = 13[\text{mm}]$$

$$0[^\circ] \rightarrow 60[^\circ] = 22[\text{mm}]$$

$\theta_i [^\circ]$	$\theta_t [^\circ]$
0	0
20	14
40	32
60	46

We begin by deriving a formula. The set up looks as follows:




Figure 1: Set Up for Part II

From the figure, we may write:

$$t = t_1(\theta_t)$$

This gives us:

$$\Delta = \frac{t}{\cos(\theta_t)} \sin(\theta_i - \theta_t)$$

We may redefine the sin term as:

$$\sin(\theta_i - \theta_t) = \sin(\theta_i) \cos(\theta_t) - \sin(\theta_t) \cos(\theta_i)$$

Plugging this back into the formula for Δ , we obtain:

$$\Delta = t(\sin(\theta_i) - \tan(\theta_t) \cos(\theta_i))$$

Next, we want to isolate θ_t :

$$\begin{aligned} \tan(\theta_t) &= \frac{\sin(\theta_i) - \frac{\Delta}{t}}{\cos(\theta_i)} \\ \theta_t &= \tan^{-1} \left(\frac{\sin(\theta_i) - \frac{\Delta}{t}}{\cos(\theta_i)} \right) \end{aligned}$$

Employing Snell's law, we may write:

$$n_2 = \frac{n_1 \sin(\theta_i)}{\sin \left(\tan^{-1} \left(\frac{\sin(\theta_i) - \frac{\Delta}{t}}{\cos(\theta_i)} \right) \right)}$$

We can use the values from the table above to calculate n_2 . An example calculation for $\theta_i = 20 [^\circ]$ is shown below:

$$n_2 = \frac{\sin(20)}{\sin \left(\tan^{-1} \left(\frac{\sin(20) - \frac{.008}{.035}}{\cos(20)} \right) \right)}$$

$$n_2 = 2.854$$

Repeating this for $\theta_i = 40, 60 [^\circ]$, we get:

$\theta_i [^\circ]$	n_2
0	0
20	2.854
40	1.925
60	2.019

Once again averaging our answers, we find $n_{avg} = 1.6995$, a bit less accurate than our first method, but still fairly close.

4 Conclusion

4.1 Questions

- Calculate the RI of the sample using the two methods and show the detailed optical path

See work in the “Results and Analysis” section.

- Given the fact that the RI of plexi-glass would decrease when increasing the wavelength (optical dispersion), how would the θ_t and θ_r in the first experiment change and how would the dislocation in the second experiment change when switching the red laser to green laser?

Given that green has a lesser wavelength than red, we know that the refraction index would increase. To compensate, the transmitted angle would have to be smaller. Since the angle would be smaller, the dislocation would be smaller as well. On the other hand, θ_r does not change, as it does not depend on the refraction index of the material being transmitted into. We know that $\theta_r = \theta_i$, and it would remain so despite any change of color.

4.2 Summary

Overall, we were successfully able to use two methods to estimate the index of refraction of an acrylic/plexi-glass shape.